



LED Support

camera specific customer help



Operation with Olympus Cameras

Olympus cameras have a 2second delay between activating the IR shutter and taking the picture. On some models this can be changed to zero but to allow **gent360 LED** to work will all Olympus cameras it is recommended that the 2 second delay is enabled.

With the Olympus version the servo movement and IR trigger happen together. With the 2 second delay the pan will have finished when the picture is taken.

(With other **gent360 LEDs** the shutter release happens 2 seconds after the pan servo movement)