



Product Support

Additional Information for OLYMPUS Cameras & gentled zoom

Olympus cameras that were originally designed for RM-1 operation have an unusual “2 channel” feature that is not well documented in the Olympus Manuals.

New Cameras from early 2004 that are advertised for use with the RM-2 do not have this feature, and should work with no problems.

After talking to Olympus Support Europe regarding the RM-1 and RM-2 we believe that gentled zoom will work with all cameras that can use either RM-1 or RM-2, however cameras originally designed for use with RM-1, and shipped with a RM-1 in the bundle may require the following procedure before gentled zoom will work:

1. Set-up and test the gentled zoom as per the Operating Manual. If it doesn't work then do the following procedure.
2. Using the RM-1 remote control, press the CH button and then the T button – keeping CH pressed. Hold until the camera flashes or beeps. If the zoom moves you didn't press the buttons together, so try again.
3. The gentled zoom will now function.

This process ensures that the camera is monitoring the correct channel for gentled zoom operation. Afterwards the RM-1 will still work as normal.